

244LD LevelStar Intelligent Buoyancy Transmitter for Level, Interface and Density – HART[®] and FOUNDATION Fieldbus



Contents

| | |
|--|-----------|
| Figures | 5 |
| Tables | 7 |
| Important Information | 9 |
| Please Note | 9 |
| Introduction | 11 |
| Features | 11 |
| Design | 13 |
| Method of Operation..... | 14 |
| Identification..... | 15 |
| Transmitter Nameplate 1 | 15 |
| Tag Number Label 2 | 16 |
| Boiler Label 3..... | 16 |
| Adjustment Data Label | 17 |
| Matching the Displacer | 17 |
| Torque Tube Material Label..... | 17 |
| Thread Label | 17 |
| Mounting | 18 |
| High Medium Temperatures | 18 |
| Mounting on Top of the Vessel..... | 18 |
| Mounting in a Side Level/Displacer Chamber | 19 |
| Mounting the Wafer Body..... | 20 |
| Displacer 204DE | 22 |
| Replacing Displacer | 22 |
| Pressure Rating..... | 22 |
| Divided Displacers | 22 |
| Damping Element | 23 |
| Use in Zone 0 Mechanics | 23 |
| Potential Equalization..... | 23 |

| | |
|---|-----------|
| Electrical Connection | 24 |
| Signal Wire Connection | 24 |
| Ground | 25 |
| Commissioning and Decommissioning | 26 |
| Decommissioning | 26 |
| Setting of Transmitter..... | 26 |
| Starting Operation | 27 |
| Manual Mode and Autorange Mode | 28 |
| Setting via Local Keys and LCD | 28 |
| Changing values | 29 |
| Linear Adjustment..... | 29 |
| Numerical Adjustment | 29 |
| Operational View | 30 |
| Menu List | 31 |
| Dimensioning of Displacer..... | 37 |
| Calculating Weight Forces..... | 37 |
| Graph for Determining Displacer Diameter | 38 |
| Measuring Span..... | 39 |
| Weight Force..... | 39 |
| Determining Displacer Diameters | 39 |
| Measuring Principle | 40 |
| Block Diagram with HART [®] Communication | 41 |
| Explanations to Block diagrams..... | 41 |
| Supply of Transmitter..... | 45 |
| General | 45 |
| Overview of Application Types..... | 45 |
| Error Messages on LCD Display and the DTM Screen | 48 |

Figures

| | | |
|----|--|----|
| 1 | 244LD Mounted on top of a Displacer Chamber..... | 12 |
| 2 | Design..... | 13 |
| 3 | Identification of Labels..... | 15 |
| 4 | Transmitter Nameplate..... | 15 |
| 5 | Boiler Label..... | 16 |
| 6 | Mounting on Top of the Vessel..... | 18 |
| 7 | Mounting in a Side Level/Displacer Chamber..... | 19 |
| 8 | Mounting the Wafer Body..... | 20 |
| 9 | Setting the 244LD LevelStar..... | 20 |
| 10 | Displacers with diameters less than 30 mm..... | 21 |
| 11 | Divided Displacers..... | 22 |
| 12 | Damping Element for the Displacer..... | 23 |
| 13 | Signal Wire Connection..... | 24 |
| 14 | Connection to ground when using an electrically non-conducting gasket..... | 25 |
| 15 | Setting via local keys and LCD..... | 29 |
| 16 | Operational View..... | 30 |
| 17 | Graph for Determining Displacer Diameter..... | 38 |
| 18 | Measuring Principle..... | 40 |
| 19 | Block diagram with HART® Communication..... | 41 |
| 20 | Smart Smoothing - Static..... | 42 |
| 21 | Smart Smoothing - Dynamic..... | 42 |
| 22 | Sensor Adjustment..... | 43 |
| 23 | Transfer function / Characteristic..... | 43 |
| 24 | Measured Value Setting..... | 43 |
| 25 | Setting of Range..... | 44 |
| 26 | Setting of Output Value..... | 44 |
| 27 | Supply via Power Supply Unit..... | 45 |
| 28 | Direct Supply..... | 46 |
| 29 | Supply via Power Supply Unit with Communication..... | 46 |
| 30 | Direct Supply with Communication..... | 46 |

Tables

| | | |
|---|--|----|
| 1 | Menu List | 31 |
| 2 | Error Messages on LCD display and on the DTM screen..... | 48 |

Important Information

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this manual or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of either symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in death or serious injury**.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in death or serious injury**.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in minor or moderate injury**.

NOTICE

NOTICE is used to address practices not related to physical injury.

Please Note

Electrical equipment should be installed, operated, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.


Introduction

The intelligent transmitter 244LD LevelStar is designed to perform continuous measurements for liquid level, interface, or density of liquids in the process of all industrial applications. The measurement is based on the proven Archimedes buoyancy principle and thus extremely robust and durable. Measuring values can be transferred analog and digital. Digital communication facilitates complete operation and configuration via PC or control system. Despite extreme temperatures, high process pressure and corrosive liquids, the 244LD measures with consistent reliability and high precision. It is approved for installations in contact with explosive atmospheres.

Features


- ◆ HART[®] 7 Protocol, 4 to 20 mA, or FOUNDATION Fieldbus
- ◆ Easy configuration using PACTware[™] and DTM
- ◆ Multilingual full text graphic LCD
- ◆ IR communication as a standard
- ◆ Easy adaptation to the measuring point without calibration at the workshop
- ◆ Linear or customized characteristic
- ◆ 32 points linearisation for volumetric measurement
- ◆ Continuous self-diagnostics
- ◆ Configurable safety value
- ◆ Local display in %, mA, or physical units
- ◆ Process temperature from -196 °C to +500 °C
- ◆ Materials for use with aggressive media
- ◆ Micro sintermetal sensor technology

Figure 1. 244LD Mounted on top of a Displacer Chamber



Design

Figure 2. Design



For left-sided mounting all inside parts are arranged in inverted manner.

- 20 Amplifier
- 22 Terminal compartment
- 121 Sensor
- 128 Heat sink
- 131 Wafer body with torque tube
- 133 Transmission lever
- 134 Torque tube
- 135 Clamping lever
- 150 Displacer with suspension chain
- LH Version for left-hand mounting

Method of Operation


The buoyancy force of the displacer 150 is transferred via transmission lever 133 and torque tube 134 to operating rod of the sensor, where it acts on free end of sensor element 121. Four thin film metal strain gauge elements are sputtered onto sensor element, which change their resistance in the ratio of the tensile or pressure tension. These four thin film metal strain gauge elements are connected as a Wheatstone full bridge supplied from amplifier.

The voltage at the diagonal bridge section which is proportional to the effective weight is fed to the electronic amplifier as an input signal. This voltage is converted via the electronic amplifier into the 4 to 20 mA or digital two-wire output signal. The amplifier is supplied by the signal current circuit in two-wire mode.

Identification

The transmitter is identified with several labels.

Figure 3. Identification of Labels



Transmitter Nameplate 1

The transmitter nameplate shows the Model Code of transmitter, the serial number and certification data.

(Example)

Figure 4. Transmitter Nameplate


| | | | | |
|---|-------|---|------------------------------|--------------------------|
| LEVEL - TRANSMITTER 244LD | | Made in France by ECKARDT S.A.S. F - 68360 Soultz | Schneider Electric | CE 0102 |
| <input type="checkbox"/> | | <input type="checkbox"/> | | |
| MODEL | _____ | | | |
| SER.No. | _____ | REV.No. | _____ | |
| ECEP | _____ | | | |
| U _i , I _i , P _i , C _i , L _i SEE TYPE - EXAMINATION CERTIFICATE | | | | <input type="checkbox"/> |
| | | | | |

ECEP: ID Number for special version

Tag Number Label 2

(Example)

Attached to amplifier



Optional label with devices according to NACE-Standard. With attached Tag Number label, on the rear side of label.

Boiler Label 3

Boiler label with nominal pressure, material, permissible pressure and temperature load, serial number, etc.

Figure 5. Boiler Label

○ BODY OF TRANSMITTER ○

MODEL | _____

SER.No. | _____

ECEP | _____

MAT. | _____

YEAR | _____

VOLUME | _____

NPS / DN | _____

CLASS / PN | _____

TEST PRESSURE | _____

SYSTEM PRESSURE | _____

PERMISSIBLE PRESSURE - TEMPERATURE RATINGS

| | | | | | | | |
|-----|--|--|--|--|--|--|--|
| °C | | | | | | | |
| bar | | | | | | | |
| MPa | | | | | | | |
| psi | | | | | | | |

AT OPERATING TEMPERATURE < -10 °C
USE BOLTS + NUTS MADE OF 1.4541

Made in France by
ECKARDT S.A.S.
F - 68360 Soultz

○ **Schneider** Electric ○ ○ **CE** ○
0036

Adjustment Data Label

Matching the Displacer

Take care of correct matching of transmitter and displacer at mounting. Each transmitter is calibrated to the respective displacer according to the ordering data in the factory. Each transmitter/displacer pair has adjustment data labels to help prevent mismatch.

Torque Tube Material Label

| |
|--|
| MATERIAL TORSIONSROHR - TORQUE TUBE 1.4404 / 1.4435 / 2.4610 / 2.4816 |
|--|

Refers to the material of the torque tube and is attached at the edge of the flange.

Thread Label

In the version with NPT threads, near the cable gland is a label describing the type of thread.

Mounting


The 244LD LevelStar is directly built onto the vessel or alternatively on a side mounted displacer chamber (e.g. 204DC). During installation, the permissible static pressure and the ambient temperature range must be observed. (see “Boiler Label 3” for more information).

High Medium Temperatures

It is important to help ensure that the max. permissible temperature of the electronics housing of 85 °C and that of the internal sensor/measuring cell of 120°C is not exceeded. For explosion-proof equipment, the information in the product specifications PSS EML0710 and in the certificates or approvals must be observed.

Mounting on Top of the Vessel

Figure 6. Mounting on Top of the Vessel




| | | | |
|------------|-------------------|------------|------------------------|
| 20 | Amplifier | 141 | Blind flange |
| 120 | Sensor housing | 142 | Protection cage / tube |
| 131 | Wafer body | 146 | Venting hole |
| 140 | Connecting flange | 150 | Displacer 204DE |

If the vessel contains a turbulent liquid a protection cage / tube should be used. It has a venting hole 146 above the maximum liquid level. Between the protection cage / tube 142 and the displacer 150 must be a gap of 5 to 10 mm.

Mounting in a Side Level/Displacer Chamber

Figure 7. Mounting in a Side Level/Displacer Chamber



- 147 Displacer chamber 204DC
- 148 Shut-off valve


When used in Zone 0, fittings resistant to flame penetration must be used.

NOTE

Mount the vessel with suitable bolts and seals (not included in the scope of delivery). Ensure that the displacer chamber is exactly vertical. Between the protection cage or tube and the displacer must be a gap of 5 to 10 mm.

Mounting the Wafer Body

Figure 8. Mounting the Wafer Body



1. Place the seal 139⁽¹⁾ on the connecting flange 140. Insert displacer in displacer chamber or vessel. Hold 244LD LevelStar 131 above connecting flange. Engage eyelet 153 of displacer chain in notch in transmission lever 133 and fit wafer body onto connecting flange. See Figure 8.

NOTICE


POTENTIAL EQUIPMENT DAMAGE

Do not drop the appended displacer and Avoid jerky load.

Failure to follow these instructions can result in equipment damage.

2. Set 244LD LevelStar to the mounting flange.

Figure 9. Setting the 244LD LevelStar



1. When using an electrically non-conducting soft gasket, the wafer body must be grounded.

3. In order to make mounting easier, mounting bracket 132 is secured with a stud 142 to connecting flange 140. You must preassemble a stud by screwing a nut 143 onto thread.
4. Insert this stud through the top of mounting bracket and connecting flange. Screw sufficient number of nuts onto thread and reduced shaft from underneath for the wafer body to be firmly in position.
5. Place seal 139⁽¹⁾ on wafer body. Place blind flange 141 on wafer body so that holes in blind flange and connecting flange 140 are aligned. Insert remaining studs. Screw on nuts and tighten gently.
6. Unscrew nut 143 and pull stud downwards.
7. Tighten the nuts on all bolts with the appropriate wrench. Proceed crosswise to avoid jamming.

| Recommended tightening torque (Pre-stressed to 70% of minimum yield point at 20°C) | | | | | | | |
|---|-------|--------|--------|--------|--------|--------|---------|
| Mat. | M12 | M16 | M20 | M24 | M27 | M30 | M36 |
| A2-70 | 40 Nm | 95 Nm | 185 Nm | 310 Nm | 450 Nm | 630 Nm | 1080 Nm |
| 1.7225 1.7709 (8.8) | 50 Nm | 120 Nm | 250 Nm | 435 Nm | 630 Nm | 860 Nm | 1500 Nm |

— **NOTE** —


Studs and nuts material depends on material of wafer body and temperature of process medium.

Note for displacers with diameters less than 30 mm

Displacers with diameters < 30 mm can also be suspended when the wafer body has already been mounted. As an aid to installation, a wire can be pulled through the hole in the eyelet 153.

The displacer is lowered through the wafer body with this wire, past the transmission lever and into the displacer chamber or vessel. The eyelet must then be hooked onto the notch 133 in the transmission lever. Finally remove the wire.

Figure 10. Displacers with diameters less than 30 mm



Displacer 204DE

Ensure correct matching of transmitter and displacer while mounting. Each transmitter is calibrated to the respective displacer according to ordering data in the factory. See “Adjustment Data Label” for more information.

Replacing Displacer

Enter the changed data of displacer on the adjustment label, see “Adjustment Data Label”.

Pressure Rating


The displacer must be designed for the pressure rating of the vessel – however, at least to the operating pressure – and ordered accordingly. Here the maximum possible temperature must be taken into consideration. Displacers made of PTFE are made from solid material, and are, therefore, suitable for all pressures.

Divided Displacers

Displacers with a length of more than 3 m (1 m with PTFE) are divided. The displacer elements are screwed together and secured with the wire clip 151 to avoid bending or damage during insertion into the vessel. The elements of displacers with $\varnothing < 13$ mm are not screwed together; they are secured with hook and eyelet 152. Additional securing is not necessary ⁽¹⁾

Lengths < 350 mm or > 3000 mm, and density ranges < 100 kg/m³ or > 2000 kg/m³ on request.

Figure 11. Divided Displacers




1. When used in Zone 0, the eyelets must also be welded.

Damping Element

In operating conditions with strong external vibrations - e.g. nearby compressor stations - the damping element (Option -D) should be used.

Figure 12. Damping Element for the Displacer



It is hooked onto the suspension chain of the displacer in place of 7 chain links (105 mm). This spring is specially matched to the resonance frequency of the displacer and is made of stainless steel 1.4310 (operating temperature up to 250 °C) or Hastelloy C (operating temperature up to 350 °C).

Use in Zone 0 Mechanics

When used in Zone 0, displacers must be secured against oscillating when

- ◆ displacer made of metal, explosion group IIC
- ◆ displacer made of metal, explosion group IIB/A, length > 3 m
- ◆ displacer made of PTFE+25% carbon, IIC/B/A, length > 3 m

The displacer is to be attached in such a way that it is not in the main filling jet stream.

Potential Equalization


When used in Zone 0, only displacers of metal or PTFE +25% carbon may be used. A potential equalization line must be mounted as an electrical bypass of the displacer suspension(s) if the residual displacer weight is < 10 N, or if more than 6 contact points are present.

To help protect from electrostatic ignition, a connection to the transmitter with good conductivity must be ensured. The volume resistance between the lower end of the displacer and ground may not exceed 1 MOhm.

Electrical Connection

Signal Wire Connection

Figure 13. Signal Wire Connection



- 22 Connecting compartment cover
- 24 Cover lock
- 38 Cable gland (permitted cable diameter 6 to 12 mm)
- 39 Cover screw
- 45 Connection terminal "+" wire cross
- 46 Connection terminal "-" section
- 47 Ground terminal max. 2.5 mm² Test sockets (Ø 2 mm) integrated in terminal block
- 48 External ground terminal
- 50 Overvoltage protection (if present)

Guide cable through cable gland 38 from the bottom; observe especially the shielding.

Check mounting cable glands if threads are matching, otherwise housing can be damaged. Cable gland 38 and cover screw 39 are interchangeable.

Connect input signal to terminals 45 (+) and 46 (-). The screw terminals are suitable for wire cross sections of 0.3 to 2.5 mm². For selection of the cable, refer to recommendation for cable types according to the IEC 1158-2.

NOTE

Transmitters are supplied without a cable gland. Select a gland that conforms to applicable Ex requirements.

— NOTE

For explosion proof devices follow reference for cable gland and cover screw in document "Safety Instructions 240 Series".


Actions

- ◆ Loosen cover lock 24 (if provided) and unscrew cover 22.
- ◆ Guide cable through cable gland and connect to terminals 45, 46, and 47.
- ◆ If necessary connect external ground terminal 48.
- ◆ Screw cover 22 and install cover lock 24 (if provided).

Ground

If connection to ground is necessary (e.g. potential equalization, protection of electromagnetic influence), ground terminal 47 or external ground terminal 48 must be connected. When using an electrically non-conducting gasket, the wafer body must be grounded by wire E with the connection flange.

Figure 14. Connection to ground when using an electrically non-conducting gasket



Commissioning and Decommissioning

In any case, installation and safety regulations have to be checked prior to commissioning. See document EX EML 0010 A: “Safety Operating Instructions”

After correct installation and connection to power supply unit, the transmitter is ready for operation:

$U > 12 \text{ V dc}$ (HART)[®]

If necessary the configuration of lower range value, upper range value and damping has to be checked. With HART[®] an ampmeter can be attached into the output current loop for check.

Decommissioning

⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Prior to decommissioning take precautions to avoid disturbances:

- ◆ Observe Ex. protection.
- ◆ Switch off power supply.
- ◆ Take precaution while using hazardous process media.
- ◆ With toxic or harmful process media, observe relevant safety regulations.

Failure to follow these instructions will result in death or serious injury.

Before dismantling the transmitter, the procedure should be followed:

1. Depressurize vessel or displacer chamber.
2. Drain off measuring medium in displacer chamber.
3. Protect the environment; do not allow measuring substance to escape. Catch and dispose them properly.

The procedure for dismantling the transmitter is the reverse of that described for mounting.

Setting of Transmitter

Zero, lower range value, upper range value and damping of the transmitter are set by manufacturer as specified in the order:

- ◆ Dimensions of displacer: Length, density, weight
- ◆ Setting Lower Range Value by weight F0:
 - ◆ without Zero elevation = 0;

- ◆ with Zero elevation = Value of elevation
- ◆ Upper Range Value corresponding to buoyancy force of displacer. Refer to “Dimensioning of Displacer”.
- ◆ Output Range and unit

Therefore, calibration at start-up is not necessary. Operating data and displacer data are stored in the transmitter according to the order. Configuration becomes necessary if this data deviates from the stored values. In case the order does not include this data, the transmitter is supplied as follows:

- ▶ displacer weight = 1.500 kg buoyancy
- ▶ force = 5.884 N (0.600 kg)
- ▶ indication = 0 to 100 %
- ▶ damping = 8 sec (90 % time)

Setting via HART[®] Protocol

- ◆ Setting with PC, PACTware[™] and DTM
- ◆ Setting with HART Communicator

Setting via Operating Push Buttons

Setting can be done by means of the push buttons at the transmitter, see “Setting via Local Keys and LCD”.

Warm-up prior Calibration and Zero Point Corrections


During final assembly at the manufacturer, ZeroBasic is adjusted. For this, the displacer data are entered from which the 244LD automatically calculates the zero point in “Auto Range” mode.

We recommend performing the ZeroCorrect function at commissioning. In this case, the transmitter is brought up to operation temperature (“hot Adjustment”) and subsequently the zero point. So the detected measurement error for the process temperatures (either very high or very low) is kept small. Inaccuracies during installation are taken into account. The function can be performed by the DTM or locally on the LCD and push buttons (Menu 4 PV offset).

If required, it may be necessary to activate or deactivate a zero point correction. For this, the SpecialZero function is provided. It is used to compensate a zero shift as a result of the influence of high or low medium temperature (e.g., during the start of the process). This function is only accessible via the DTM. For details about the DTM, follow the instructions on the screen.

Starting Operation

After starting (after power-on) the logo is briefly displayed, then device information.




Device Type

Measuring task

Version

and then the operational view.



The operational view is the display in normal operation.

Manual Mode and Autorange Mode

When ordering, the customer has stated range and the density of the measuring medium (or the densities of the media). Using this data the real displacer was manufactured.

The default mode is set to **Autorange** for a displacer. The displacer data (diameter, length, weight) and the density of the media were stored before delivery via FDT / DTM in the 244LD LevelStar. From this data, PV-offset and Upper Range Value URV are calculated automatically, which allows an immediate operation without any additional calibration in the field.

However, if the manual method is preferred, the values can be entered manually.

In Manual mode the classic method is possible to take over the respective values of the buoyancy forces with the operating conditions for 0% (with level: empty vessel) and 100% (with level: full vessel).


— NOTE —

The operation of the transmitter is described with local keys. For the setting of all values and special functions we recommend the use of the FDT DTM technology. This requires only a PC (notebook), a modem and the FDT software (PACTware™). The operation is done using the FDT DTM technology. If you use local keys, not all features are accessible. You can download the software from the Schneider Electric website.

Setting via Local Keys and LCD

The operating parameters and settings can be viewed on site and in some cases changed. For local operation a full graphic LCD is available and 2 buttons on the outside of housing. Inside the unit there are no other controls.

Figure 15. Setting via local keys and LCD



After shifting the key protection cap A, insert screw driver pin ($\varnothing < 3$ mm) into hole B and press down to the second pressure point.

Starting from the operational view,

- ◆ the 2 button switches to details of the operating values
- ◆ the 1 button switches to the menu selection,

For more information, see Figure 16.

NOTE

If no button is pressed within 5 minutes, the display returns automatically to the operational view.

Changing values

Linear Adjustment

Linear adjustment is used for example in PV-offset, damping and LCD contrast:

The current value is displayed. With button 2 MORE the value is increased. If the largest value is reached, starts again from beginning with the smallest value. The button has auto repeat. Stop with button 1 DONE. After that, even queried whether the change should be saved.


Numerical Adjustment

Numerical Adjustment is used for example in measuring range values:

The current value is displayed, and the first digit (or sign) is selected. Each time the button 1 CHANGE is pressed the number is counted up, until the desired number is reached. With button 2 NEXT the next number is marked and can be changed, etc. After that, even queried whether the change should be saved.

Operational View

Figure 16. Operational View



Menu List

Table 1. Menu List






| Menu | Description |
|---|--|
| Menu 1: Back | |
|  <p>MAIN MENU 244LD 1 Back 2 Menu Language 1 DOWN YES2</p> | <p>Back to Operational view.</p> <p>Note: When selecting YES 2 it goes back to the operating view. All sub-menus start with a “Back” feature that lets you come back to the previous menu.</p> |
| Menu 2: Menu Language | |
|  <p>MAIN MENU 244LD 2 Menu Language 3 Set Mode 1 DOWN YES2</p> | <p>With YES 2 it goes to language selection.</p> |
|  <p>2 Menu Language 2.1 Back 2.2 English 2.3 Deutsch 2.4 Français 1 DOWN YES2</p> | <p>There are 3 menu languages, standard English, German and French. From the factory, active language is always English. With 1 DOWN the desired language is selected and becomes active with confirming with YES 2. All texts are now displayed in the chosen language. Then it goes automatically back to the Main menu.</p> |
| Menu 3: Set Mode | |
|  <p>MAIN MENU 244LD 3 Set Mode 4 PV-Zero 1 DOWN YES2</p> | <p>With YES 2 it goes to Autorange or Manual selection. See “Setting via Local Keys and LCD”.</p> |
|  <p>3 Set Mode Auto Mode Manual Mode 1 MODUS OK2</p> | <p>With 1 MODE you switch from Autorange to Manual Mode. If this is to expect a change in the output value, a message appears. After confirming with OK 2 back to the main menu. Switching from Manual- to Autorange Mode: Requires reset to factory settings, if manual set data allows no calculations. See Menu 5.6.</p> |

Table 1. Menu List (Continued)







| Menu | Description |
|---|---|
| Menu 4: Setting PV-Offset | |
|  | <p>With YES 2 it goes to setting PV-Offset.</p> |
|  | <p>With YES 2 PV-Offset can be set, regardless of the mode Autorange or Manual.</p> |
|  | <p>Setting on Linear adjustment in 0.1% increments, see “Setting via Local Keys and LCD”. The expected impact of the change can be seen on the primary variables in the second line. The resulting automatically calculated PV-offset is displayed on the third line to observe the change and possibly return to the former value.</p> |
|  | <p>With YES 2 the current process value (Level: Displacer is not in the medium) is taken over as the physical zero point. Note: This menu item is only for manual mode and therefore the auto range mode is locked (indicated by a padlock symbol).</p> |
|  | <p>By confirmation with YES 2 the current value will be saved as Lower Range Value.</p> |
| Menu 5: Additional Functions | |
|  | <p>With YES 2 it goes to the following sub menus:</p> |

Table 1. Menu List (Continued)







| Menu | Description |
|---|---|
|  | <p>With YES 2 it goes to setting the damping.</p> |
|  | <p>At first the current value is displayed. The value can now be adjusted with the MORE 2 button in steps of 1 second Linear adjustment, see “Setting via Local Keys and LCD”. Then back to the menu.</p> |
|  | <p>With YES 2 it goes to the Range setting in the Autorange mode. In Autorange mode, the densities can be changed and then immediately taken into account in the automatic calculation.</p> |
|  | <p>With YES 2 to enter the density of the lower medium.</p> |
|  | <p>The value is entered using Numerical adjustment, see “Setting via Local Keys and LCD”. Finally, the value must be confirmed and is saved. If density of lower medium is lighter than the density of upper medium, an error message appears, and the value is not stored.</p> |
|  | <p>With YES 2 to enter the density of the upper medium. (Proceed as with lower density.) Note: For Level measurement the value is 0.000.</p> |

Table 1. Menu List (Continued)







| Menu | Description |
|---|---|
|  <p>5.3 Auto Range 5.3.4 show range 5.3.1 Back 1 DOWN YES2</p> | <p>With YES 2 the current Measuring range is displayed:</p> |
|  <p>Range=100.00 N LRV= 0.00 N URV= 100.00 N BACK2</p> | <p>Measuring range Lower Range Value Upper Range Value With BACK 2 back to previous menu.</p> |
|  <p>5 Add. functions 5.4 Man. Range 5.5 Reset Device 1 DOWN YES2</p> | <p>With YES 2 it goes to the Range setting in Manual mode. After setting the operating conditions for 0% (at level: vessel empty) or 100% (at level: vessel full) each take over the value of the buoyancy force. Or by values input at 0% and 100%. Note: Feature is only available in Manual mode, Autorange mode is locked (padlock icon in the LCD).</p> |
|  <p>5.4 Man. Range 5.4.2 LRV (0%) 5.4.3 URV (100%) 1 DOWN YES2</p> | <p>LRV - take over the Lower Range Value (0%) With YES 2 the following display appears:</p> |
|  <p>< 5.000 N > apply as 0%? LRV= 0.000 N 1 NO YES2</p> | <p>By confirmation with YES 2 the current value is saved as Lower Range Value.</p> |
|  <p>5.4 Man. Range 5.4.3 URV (100%) 5.4.4 set LRV 1 DOWN YES2</p> | <p>URV - take over the Upper Range Value (100%) (Proceed as with Lower Range Value.)</p> |

Table 1. Menu List (Continued)











| Menu | Description |
|--|---|
|  <pre> 5.4 Man. Range 5.4.4 set LRV 5.4.5 set URV 1 DOWN YES2 </pre> | <p>LRV - enter the Lower Range Value (0%) With YES 2 the following display appears:</p> |
|  <pre> 5.4.4 set LRV +010.000 % min= 000.000 % 1 EDIT NEXT2 </pre> | <p>The value is entered using Numerical adjustment, see "Setting via Local Keys and LCD". In the third line, the minimum value is displayed. Finally, the value must be confirmed and is then stored as Lower Range Value.</p> |
|  <pre> 5.4 Man. Range 5.4.5 set URV 5.4.1 Back 1 DOWN YES2 </pre> | <p>URV - enter the Upper Range Value (100%) (Proceed as with Lower Range Value.)</p> |
|  <pre> 5 Add. functions 5.5 Reset Device 5.6 Fact.Setting 1 DOWN YES2 </pre> | <p>With YES 2 it goes to function selection. After a further confirmation the reset of electronics is running. Same effect as Power-on.</p> |
|  <pre> 5 Add. functions 5.6 Fact.Setting 5.1 Back 1 DOWN YES2 </pre> | <p>With YES 2 it goes to function selection. Note: All custom settings are reset to the factory-defined state and is lost.</p> |
| Menu 6: Device Information | |
|  <pre> MAIN MENU 244LD 6 Device-info 7 LCD config 1 DOWN YES2 </pre> | <p>YES 2 displays the data stored in the transmitter, such as</p> <ul style="list-style-type: none"> ▶ Tag Number ▶ Tag Name ▶ Device type ▶ Revision Nr ▶ Displacer data ▶ System-Lifetime |

Table 1. Menu List (Continued)

| Menu | Description |
|---|--|
| Menu 7: LCD Configuration | |
|  | <p>With YES 2 it goes to settings for the LCD:</p> |
|  | <p>With YES 2 it goes to selection of LCD orientation:</p> |
|  | <p>With 1 ROTATE is the text "on the feet". With confirming with OK 2 it goes back to the menu.</p> |
|  | <p>With YES 2 the LCD contrast is adjusted. Linear adjustment, see "Setting via Local Keys and LCD".</p> |

Dimensioning of Displacer

Calculating Weight Forces

(also see VDI/VDE-Guideline 3519, sheet 1)

Displacer Length = Measuring Range

| Measurement type | Weight forces | | 0 % | 100 % |
|---|--|--|-----|-------|
| | Lower range value = 0 % output signal | Upper range value = 100 % output signal | | |
| Liquid level (ρ_2 = negligible) | $F_0 = F_G$ | $F_{100} = F_G - V \cdot g \cdot \rho_1$ | | |
| Interface (ρ_2 = not negligible) | $F_0 = F_G - V \cdot g \cdot \rho_2$ | | | |
| Density (ρ_2 = min. density, ρ_1 = max. density) | | | | |

Displacer Length > Measuring Range

(without elevation)

| Measurement type | Weight forces | | 0 % | 100 % |
|---|--|---|-----|-------|
| | Lower range value = 0 % output signal | Upper range value = 100 % output signal | | |
| Liquid level (ρ_2 = negligible) | $F_0 = F_G$ | $F_{100} = F_G - V \cdot g \cdot \rho_1 \frac{h_b}{L}$ | | |
| Interface (ρ_2 = not negligible) | $F_0 = F_G - V \cdot g \cdot \rho_2$ | $F_{100} = F_G - V \cdot g \cdot (\rho_1 \frac{h_b}{L} + \rho_2 \frac{L - h_b}{L})$ | | |

Displacer Length > Measuring Range

(with elevation)

| Measurement type | Weight forces | | 0 % | 100 % |
|---|---|---|-----|-------|
| | Lower range value = 0 % output signal | Upper range value = 100 % output signal | | |
| Liquid level (ρ_2 = negligible) | $F_0 = F_G - V \cdot g \cdot \rho_1 \frac{h_0}{L}$ | $F_{100} = F_G - V \cdot g \cdot \rho_1 \frac{h_0 + h_b}{L}$ | | |
| Interface (ρ_2 = not negligible) | $F_0 = F_G - V \cdot g \cdot (\rho_1 \frac{h_0}{L} + \rho_2 \frac{L - h_0}{L})$ | $F_{100} = F_G - V \cdot g \cdot (\rho_1 \frac{h_0 + h_b}{L} + \rho_2 \frac{L - h_b - h_0}{L})$ | | |

| | | | | | |
|-----------|--------------------|---|----------|-----------------------|---|
| F_G | [N] | Weight force of displacer in atmosphere | ρ_1 | [kg/m ³] | Liquid density |
| F_0 | [N] | Weight force action on suspension point of displacer at lower range value | ρ_2 | [kg/m ³] | Density of gas or lighter liquid |
| F_{100} | [N] | Weight force action on suspension point of displacer at upper range value | g | [m/s ²] | Local acceleration due to gravity (e.g. 9.807 m/s ²) |
| F_A | [N] | Buoyancy force of displacer ($F_A = F_0 - F_{100}$) | L | [m] | Displacer length |
| V | [m ³] | Displacer volume (specified on data label in cm ³) | h_0 | [m] | Lower range value |
| | | | h_b | [m] | Measuring span |


1) ρ_1 is negligible if $\rho_2 =$ gas at atmospheric pressure or with ratio $\rho_2 : \rho_1$ less than 0.5%

NOTE

1 kg generates a force of 9.807 N

Graph for Determining Displacer Diameter

Figure 17. Graph for Determining Displacer Diameter



Measuring Span

The transmitter is designed for a buoyancy force measuring span of minimum 2 up to maximum 20 N.

Weight Force

The maximum weight of the displacer F_A max. is 25 N for level measurements. For density or interface measurements, the displacer must be dimensioned so that after deducting F_A of the lighter process media, the remaining force F_0 does not exceed 25 N.

Determining Displacer Diameters

For optimum use of the transmitter, the displacer should be dimensioned so that the greatest possible buoyancy force is generated over the measuring range. On the other hand, the maximum possible diameter of the displacer must be taken into consideration.

In the above graph the displacer diameter can easily be estimated dependent on the measuring span and the buoyancy force.

The following equation can be used to exactly dimension the displacer:

$$D = 1000 \sqrt{\frac{4 F_A}{\pi g (\rho_1 - \rho_2) L}} \quad [\text{mm}]$$

D = Outside diameter of displacer in mm

F_A = Buoyancy force of displacer in N

g = Acceleration due to gravity (9.807 m/s²)

ρ_1 = Density of heavier liquid in kg/m³

ρ_2 = Density of gas or lighter liquid in kg/m³

L = Measuring span in m

Example:

Measuring span: 1.500 m

$\rho_1 = 1000 \text{ kg/m}^3$

$\rho_2 = \text{negligible}$

Measuring Principle

(see VDI/VDE Guideline 3519, sheet 1)

Any body immersed into a liquid is subject to Archimedian buoyancy force which depends on the liquid density. This is exploited to determine liquid level, density and interface level by suspending a displacer with constant cylindric shape into a liquid. Changes in buoyancy forces are proportional to liquid level changes and are converted to a measuring signal.

The displacer is fully immersed for density and interface level measurement.

The following applies in general to the buoyancy force acting on the displacer:

$$F_A = V_x \cdot \rho_1 \cdot g + (V - V_x) \cdot \rho_2 \cdot g$$

F_A : Buoyancy force

V : Volume of displacer

V_x : Volume of medium displaced by measuring body with density ρ_1

ρ_1 : Average density of heavier medium


ρ_2 : Average density of lighter medium

g : Local acceleration due to gravity

F_G : Displacer body weight force


The force acting on the transmitter is inversely proportional to liquid level changes.

Figure 18. Measuring Principle



Block Diagram with HART[®] Communication

Figure 19. Block diagram with HART[®] Communication



Explanations to Block diagrams

Sensor

The force sensor is a Wheatstone bridge of four metal strain gauge elements and a Ni100 resistor for temperature measurement.

Line Frequency Suppression Filter

This is the selection to filter the noise signal 50 Hz or 60 Hz.

Linearization and Temperature Compensation of Sensor characteristic

The sensor signal is linearized and temperature-compensated by the included sensor temperature. Linearization takes place via the so-called fingerprint data, which are determined during the production for each sensor. In factory the fingerprint data are loaded into the amplifier.

Smart Smoothing

In factory the Smart Smoothing Band is set to 2% of sensor range. The Integration Time of the average value is set to 10 seconds.

Figure 20. Smart Smoothing - Static






Figure 21. Smart Smoothing - Dynamic



Sensor Adjustment

Zero and span of force sensor are adjusted in factory. It is possible to calibrate Zero (situation alignment) with the external keys.


Figure 22. Sensor Adjustment



Transfer function / Characteristic

The characteristics are available as linear and customized. With "customized" there are 32 x/y-values available. Standard with Level is linear.


Figure 23. Transfer function / Characteristic



Measured Value Setting

Define the measured value and unit.


Figure 24. Measured Value Setting



Setting of Range

The measuring range is the range between Lower Range Value and Upper Range Value. Lower Range Value is the weight of the displacer. Lower Range Value without elevation is 0. With elevation, the value of elevation has to be entered.


Figure 25. Setting of Range



Setting of Output Value

The output value is the measured value between Lower Range Value and Upper Range Value. Value and unit are freely selectable. The replacement value affects the output.

Figure 26. Setting of Output Value



Replacement / Substitute Value (HART[®] only)

In case of a detected error, output holds last value or gives a configurable Replacement value. If the detected error does not exist any longer, then last value and / or Replacement value is taken back (automatically or manually).

Multi-drop (HART[®] only)

With FDT-DTM or a Hand held Terminal it is possible to switch HART[®] Amplifier between analog and Multi-drop. With HART[®] mode Multi-drop, the output has a digital signal, the measured value is modulated to a 4 mA DC signal. FDT-DTM Software enables to simulate the measured value and to write output values directly to the output.

Filter

The output signal is damped. Damping time is set from 0 to 32 seconds.

Supply of Transmitter

General

Depending on the transmitter application varying demands are made on the supply. See “Overview of Application Types” for more information. The wire diagrams are shown in the following figures.

The power supply units for different applications (direct / via power supply unit of transmitters, HART® / without communication, intrinsically / not intrinsically) are listed in the following table.

All listed supply devices are available for intrinsically safe and/or non-intrinsically safe application.


Application and associated supply:

| Application | Supply (recommended) |
|-----------------------|------------------------------|
| without communication | direct, Universal Ex-Barrier |
| HART® | direct, Universal Ex-Barrier |

Overview of Application Types


Supply via Power Supply Unit

Figure 27. Supply via Power Supply Unit




Direct Supply

Figure 28. Direct Supply




Supply via Power Supply Unit with Communication

Figure 29. Supply via Power Supply Unit with Communication



Direct Supply with Communication

Figure 30. Direct Supply with Communication



Direct Supply with Communication is

- ◆ 42 V for non-Ex as shown in Figure 30
- ◆ 24 V for PA/FF ATEX
- ◆ 30 V for HART Ex
- ◆ 32 V for PA/FF/HART CSA approval

Supply via Power Supply Unit

This supply is for normal use. Interferences are prevented due to galvanic separation of measurement loop, load, and power supply in the power supply unit. See Figure 27.

Direct Supply

This most simple version can be recommended only for single galvanically separated supply or measurement loops. See Figure 28.

$$R_{B\max} = (U_{\max} - 12 \text{ V}) / I_{\max}$$

U_{\max} : max. permitted voltage (according to product specifications), depends on type of transmitter and explosion protection.

I_{\max} : 23 mA HART®

Communication

In contrast to conventional operating mode in the two-wire loop a minimal load for all communication modes has to be available. If this load is selected too low, the communication is short-circuited. Additionally, the line lengths have to be limited to the maximum permitted values for the respective communication.

Standard values:

| Communication | HART® |
|-----------------------|----------|
| Min. load | 250 Ohm |
| Max. capacity of line | < 200 nF |
| Max. length of line | ~ 3300 m |

The respective wiring diagram is shown in Figure 29.

Figure 30 shows the respective wiring diagram without power supply unit for galvanically separated loops. The operating tool HART Communicator or PC with PACTware™ and DTM can be connected to the labeled positions. Depending on the application the regulations for explosion protection have to be observed also for the operating tools.

Intrinsically Safe Application

For intrinsically safe application generally the use of a respective power supply unit is recommended. Wiring should be done as per respective national and international standards and regulations - as described in "Supply via Power Supply Unit". If communication is required also, the guidelines have to be observed. In addition, the application of the operating tools and their permitted limit values are to be observed.

Error Messages on LCD Display and the DTM Screen

Table 2. Error Messages on LCD display and on the DTM screen

| Message Text | I _{out} | Instrument State | Possible Cause | Action | Remarks |
|---|-------------------|--|--|---|---|
| INT CALIB FAILED INT CALIB INVAL (a) | | | Not implemented in LevelStar | No | |
| SENSOR INVALID | FailSafe 24 mA | Safety related <ul style="list-style-type: none"> ▶ Level measurement not usable ▶ HART-communication via modem and IR service port is available. | Measuring Cell failure <ul style="list-style-type: none"> ▶ Electronic internal diagnosis detects invalid measuring cell values ▶ Wrong sensor/electronic replace procedure | <ul style="list-style-type: none"> ▶ Check and compare code on sensor to be in accordance with Fingerprint Data code loaded. ▶ Repeat factory Basic Calibration ▶ Check sensor wire connection ▶ Load right fingerprint data, then restart the device and finally do sensor calibration (Sensor Trim) | Do not change electronic module from instrument A to B. Should be carried out by experienced personal only. Additional know how and experience required for correction procedure. |
| OUT OF SENS LIMIT | | | Not implemented in LevelStar | No | |
| SENS TEMP LIMIT | FailSafe 24 mA | Safety & process related Temperature is lower -60 °C or higher +150 °C HART-communication via modem and IR service port is available. | Specified temperature limits exceeded | <ul style="list-style-type: none"> ▶ Read out data via DTM ▶ Check Status and Extended Status message information accordingly ▶ Check temperature of environment ▶ Check process temperature ▶ Check temp sensor (Ni 100 element) inside measuring cell Change sensor if necessary | In case instrument output is on Fail Safe safety value check Failsafe configuration. |
| | 3.8 .. 20.5 mA | Indicated as Status Message only. Temperatures limits | | | |
| ELEC TEMP LIMIT | | Warning message: Device is not in safe mode. | <ul style="list-style-type: none"> ▶ Electronic Temperature out of limits. ▶ Temperature is between -40°C to -60°C or 89°C to 105°C | Ambient or process temperature is too low/high | |
| MEAS RANGE INVAL (b) | | | Not implemented in LevelStar | No | |

Table 2. Error Messages on LCD display and on the DTM screen (Continued)

| Message Text | I _{out} | Instrument State | Possible Cause | Action | Remarks |
|--|------------------|---|---|--|---|
| PV OUT OF LIMIT | | Warning message: Device is not in safe mode | PV out of limits (<-30 % or >110 %) | <ul style="list-style-type: none"> ▶ Check displacer weight ▶ Check measure range and zero point | |
| VAR OUT OF LIMIT OUT OF LIMITS (a) | | See "TEXTS ARE WRONG" or "DIAGNOSTIC ERROR" | This error message is a reaction of the "TEXTS ARE WRONG" or "DIAGNOSTIC ERROR" | See "TEXTS ARE WRONG" or "DIAGNOSTIC ERROR" | |
| ANALOG OUT SATUR CURR OUT OF LIMIT (a) | | Warning message for I _{out} out of limits. Device is not in safe mode. | The output current is out of limits: 3,8 mA (-1,25 %) and 20,5 mA (103, 123 %) | Check measure range | |
| CURRENT FIXED | | Warning message: Device is not in safe mode | Output current is fixed (for example current calibration or critical error) | No | |
| COLD START | | Warning message: Device is not in safe mode | Shows that the device was restarted during the safety mode | No | |
| CONFIG. CHANGED | | Warning message: Device is not in safe mode | Configuration has been changed | The message can be reset with DTM or HHT with "reset status" function | |
| OUT OF MEAS RANG | 3.8 .. 20.5 mA | Warning message: Device is not in safe mode | PV is out of measure range | check measure range | |
| FINGER PRINT ERR | | Warning message: Device is not in safe mode | The raw is >15 % or < -115 % | <ul style="list-style-type: none"> ▶ Check displacer weight ▶ Check finger print data | The device is not in normal operation. Sensor calibration is missing. |
| LANG TEXT ERROR TEXTS ARE WRONG (a) | | Warning message: Device is not in safe mode Device is not yet calibrated | internal problem with the language texts | <ul style="list-style-type: none"> ▶ restart the electronic ▶ try to download the third language via DTM | |
| DIAG INCOMPLETE DIAGNOSTIC ERROR (a) | Fail safe 24 mA | Device is in SIL mode: <ul style="list-style-type: none"> ▶ Level measurement not usable ▶ HART-Communication via Modem and IR service port is available. | Diagnostic function (s) was not executed. | Execute sensor calibration | |
| | | Warning message: Device is not in SIL mode | | | |

Table 2. Error Messages on LCD display and on the DTM screen (Continued)

| Message Text | I _{out} | Instrument State | Possible Cause | Action | Remarks |
|---------------------------------------|---------------------|--|---|---|--|
| DISPL. TOO LIGHT | Fail safe 24 mA | No Level Measurement Instrument in Safe Mode Safety related for FW-Versions <= 7.69.5 or in SIL mode | <ul style="list-style-type: none"> ▶ Sensor value above 10 % of upper max. Span limit (> 110 %). ▶ Displacer weight remaining < 0.500 kg ▶ Displacer is driven upwards by excessively streaming process fluid ▶ Displacer is too light ▶ Displacer is missing or has dropped | <ul style="list-style-type: none"> ▶ Ensure displacer is hooked up correctly. ▶ Ensure displacer is hanging free ▶ Ensure displacer is in defined measure range position inside chamber or vessel | From FW-Version >= 8.X, the DTM Fail Safe menu will offer the possibility to configure whether fail safe function for Displacer Too Light will be activated or not |
| | 20.5 mA | Indicated as Status Message only for FW-Versions >= 8.X or not in SIL mode | | | |
| NO FACT SETTINGS | | Warning message: Device is not in safe mode | Not all factory calibrations were executed | Make all calibrations and store it as factory | |
| LOOP CURRENT ERR ILL LOOP CURRENT (a) | Fail safe 24 mA | NAMUR43 related <ul style="list-style-type: none"> ▶ Level measurement not usable ▶ HART-Communication via Modem and IR service port is available. | Measured and digital current value has reached a deviation of 1.0 % | <ul style="list-style-type: none"> ▶ Perform User mA-Calibration in DTM to recalculate the current diagnostic reference values ▶ Output damping or Smart Smoothing damping must be at least 1 sec. ▶ Change electronic | |
| | Fail safe 3.6 mA | For FW-Versions <= 7.69.5, see the description of the error message "PWR SPPLY INSUFF" | | | |
| SENS. CURRENT ERR | Fail safe 24 mA | <ul style="list-style-type: none"> ▶ Level measurement not usable ▶ HART-communication via modem and IR service port is available. | <ul style="list-style-type: none"> ▶ Sensor current failure ▶ Sensor defect | <ul style="list-style-type: none"> ▶ Check sensor wire connection ▶ change sensor ▶ change electronic | |
| SENS REF ERROR | Fail safe 24 mA | <ul style="list-style-type: none"> ▶ Level measurement not usable ▶ HART-communication via modem and IR service port is available. | Sensor Reference voltage failure (Electronic failure) | change electronic | |
| TEMP SENS FAILED TEMP -SENS INVAL (a) | Fail safe 24 mA | <ul style="list-style-type: none"> ▶ Level measurement not usable ▶ HART-communication via modem and IR service port is available. | Temperature measurement failure (Measuring cell internal NI 100 temp. sensor failure) | change electronic or sensor | |
| EL TEMP SENS ERR | Fail safe 24 mA | <ul style="list-style-type: none"> ▶ Level measurement not usable ▶ HART-communication via modem and IR service port is available. | Temperature is < -60°C or > 105°C | change electronic | |

Table 2. Error Messages on LCD display and on the DTM screen (Continued)

| Message Text | I _{out} | Instrument State | Possible Cause | Action | Remarks |
|---|------------------|--|---|---|--|
| WATCHDOG ERROR | Fail safe 24 mA | <ul style="list-style-type: none"> ▶ Level measurement not usable ▶ HART-communication via modem and IR service port is available. | Watchdog has detected a failure (hardware or software related) | <ul style="list-style-type: none"> ▶ check FW-Version and update to the latest one ▶ if FW >= 7.69.5, exchange electronic | |
| | Fail safe 3.6 mA | | | | |
| ADC GAIN ERROR | Fail safe 24 mA | <ul style="list-style-type: none"> ▶ Level measurement not usable ▶ HART-communication via modem and IR service port is available. | A/D Converter failure | <ul style="list-style-type: none"> ▶ Start a new sensor calibration ▶ Check FW-Version and update to the latest one ▶ if FW => 8.xx.x, exchange electronic | |
| INT REF ERROR 100 OHM ERROR (a) | Fail safe 24 mA | <ul style="list-style-type: none"> ▶ Level measurement not usable ▶ HART-communication via modem and IR service port is available. | electronic defect | change electronic | |
| ADC BIT ERROR | Fail safe 24 mA | <ul style="list-style-type: none"> ▶ Level measurement not usable ▶ HART-communication via modem and IR service port is available. | electronic defect | change electronic | |
| SYS OFFSET ERROR | Fail safe 24 mA | <ul style="list-style-type: none"> ▶ Level measurement not usable ▶ HART-communication via modem and IR service port is available. | <ul style="list-style-type: none"> ▶ Electronic defect ▶ Sensor recalibration (Sensor Trim) required after the electronic change | <ul style="list-style-type: none"> ▶ Perform recalibration (Sensor Trim) ▶ Change electronic if recalibration is not solving the issue | |
| HART MODEM FAIL HART MODEM FIRMW (a) | Fail safe 24 mA | For FW-Versions <= 7.69.5 For FW-Versions >= 8.x | <ul style="list-style-type: none"> ▶ No HART modem firmware download ▶ HART-modem chip is defect | <ul style="list-style-type: none"> ▶ download a new modem firmware ▶ change the electronic | Internal microchip communication test failed during internal diagnosis routine |
| PWR SPPLY INSUFF | Fail safe 3.6 mA | <ul style="list-style-type: none"> ▶ Level measurement not usable ▶ HART-communication via modem and IR service port is available | <ul style="list-style-type: none"> ▶ Supplied power is too low to generate the required current. ▶ Typical error value on LCD = 1111.11 | <ul style="list-style-type: none"> ▶ Check power supply ▶ Check connection compartment ▶ Measure supplied voltage at transmitter terminals in failure state. ▶ Assure loop arrangement and power supply in use is fulfilling the demands according to PSS EML0710 G-(en) 244LD. | In case the current delivered by the power supply is insufficient the transmitter is not able to drive the current required. According to NAMUR the output has to go to a low failsafe value = 3.6 mA. |
| HI_ALARM (b) | | Warning message: Device is not in safe mode | PV is over the Hi-Alarm limit | check measure range or your process | |

Table 2. Error Messages on LCD display and on the DTM screen (Continued)

| Message Text | I _{out} | Instrument State | Possible Cause | Action | Remarks |
|-----------------|------------------|---|----------------------------------|-------------------------------------|---------|
| HI_HI_ALARM (b) | | Warning message: Device is not in safe mode | PV is over the Hi-Hi-Alarm limit | check measure range or your process | |
| LO_ALARM (b) | | Warning message: Device is not in safe mode | PV is over the Lo-Alarm limit | check measure range or your process | |
| LO_LO_ALARM (b) | | Warning message: Device is not in safe mode | PV is over the Lo-Lo-Alarm limit | check measure range or your process | |

- a. = Firmware version < 8.XXX
- b. ** = Firmware version = 9.XXX

Schneider Electric Systems USA, Inc. Global Customer Support
 70 Mechanic Street Inside U.S.: 1-866-746-6477
 Foxboro, MA 02035 Outside U.S.: 1-508-549-2424
 United States of America <https://pasupport.schneider-electric.com>
<http://www.se.com>

Copyright 2010-2021 Schneider Electric Systems USA, Inc. All rights reserved.

The Schneider Electric brand and any trademarks of Schneider Electric SE or its subsidiaries are the property of Schneider Electric SE or its subsidiaries. All other trademarks are the property of their respective owners.

