

# If you thought your Chessell circular recorder was becoming obsolete, then think again.

# **NANO392**

NANO392 provides a seamless upgrade incorporating Eurotherm's latest graphical recording technology.

#### Crystal clear, color display

This secure recording device with a full color ¼ VGA display enables the user to customize the display in a trend format, bar graphs or numerically.

### **Data Acquisition and Recording**

Data is recorded in a secure incorruptible UHH format 50Mb of integral flash memory, removable data via USB and data transfer via FTP for connection to a remote server.

#### **Key Features**

- Secure data recording
- Four universal isolated inputs
- USB-removable data storage
- Ethernet communications
- Math
- Totalizers
- Web server



**Platen Assembly** 

## **Simple On-Site Conversion**

- Disconnect the power supply
- Unplug the chart platen
- Remove two hinge screws and lift off the chart platen
- Remove all the circuit boards
- Replace the chart platen with the NANO392 platen
- Mount the termination assembly in place of the input board.
- Reconnect the termination assembly to the field wiring
- Connect the power leads to the recorder power supply terminal
- Configure the NANO392 with parameters of the circular recorder

From This



Chessell 392

This



**NANO392** 

to